

MODULAR PLATFORM SYSTEM

ASSEMBLING INSTRUCTIONS FOR USE WITH 'END'-STIRRUP

1. Fit side frames to "U"-frames with "QUICK"-pins.
Repeat until you have required platform length.

600mm ID
715mmOD

2. Fit stirrups, castor wheels and guard rail post in "U"-frames.
Secure all parts with "QUICK"-pins.

3. Place deck sections between side frames.
Fit guard rails and secure with "QUICK"-pins.
Fit required number of wall rollers.

4. Install central control box or power yoke on guard rail.
Install ASTRO hoists in accordance with ASTRO operating instructions.

1m,2m,3m
bay lengths

ATTENTION!
AFTER RIGGING IS COMPLETED CARRY
OUT ROUTINE TESTS TO ENSURE SAFE
AND CORRECT OPERATION!

