

## RISK ASSESSMENT & CONTROL MEASURES INSTANT SNAPPY $_{\mathsf{TM}}$ WORK STAND

Instant Scaffolds WA PO Box 129

Burswood WA 6100

Ph: 9451 9400 Fx: (08) 9451 9444

Task Description	<u>Hazard</u>	Class 5	Class 4	Class 3	Control Measures	Class 2	Comments	Responsible Operator/Supervisor
Erection	Unstable Ground			✓	Ensure Instant Snappy is used on firm level surface.	<b>√</b>	Relevant training induction	Supervisor
	Manual Handling			<b>✓</b>	Ensure correct lifting techiques are used, bend knees not your back	<b>√</b>	Relevant training	All
	Body Stressing			✓	Ensure fingers are well clear of snap out hinge joint.	✓	Relevant training	All
	Power Lines (electrocution)	✓			Ensure relevant authority has disconnected power or insulated power supply prior to use.	<b>√</b>	Relevant training	Supervisor
	Collapse			✓	Ensure Instant Snappy braces snap into position and platform is securely located.	<b>✓</b>	Relevant training	All
	Head, Eye Injury, Cuts, Burns etc.		✓		Wear hard hats and all relevant personal protection equipment.	<b>√</b>	Relevant training and induction	All
Use of Instant Snappy	Electrocution	✓			Earth leakage switch not installed	✓	Relevant site safety induction.	All
		✓			Working to close to power lines	✓	Relevant site safety induction.	All
	Overturning	✓			Ensure correct ingress and egress is through ends of Instant Snappy.	<b>√</b>	Relevant training	All
		✓			Ensure Platform is placed at correct level. Should be placed no higher than 3rd Rung	<b>√</b>	Relevant training	All
		<b>√</b>			Ensure all castors are locked	<b>√</b>	Relevant training	All
	Collapse	✓			Adhere to SWL (Safe Working Load) of Instant Snappy. Do not overload with materials or personnel.	<b>√</b>	Relevant training	All
	Personal injury			✓	Ensure helmets and all personal protection equipment are worn at all times.	<b>√</b>	Relevant induction required	All
	Fall from scaffold	<b>√</b>			Do not remove any components that could render the Instant Snappy unsafe.	<b>✓</b>	Site specific induction	All
		✓			Handrails to be used where a person can fall more than 1.8m.	✓	Relevant training	Supervisor/All
		✓			Do not move Instant Snappy while person working on it.	✓	Relevant training	All
Dismantle of Instant Snappy	Falling debris	✓			Ensure work platform is clean prior to dismantle	✓	Site specific induction	Supervisor/All
	Overturning		✓		Do not collapse Instant Snappy until platform has been removed.	✓	Site specific induction	Supervisor
	Personal injury			<b>√</b>	Wear all personal protective equipment.	<b>√</b>	Site specific induction and training	All
				<b>✓</b>	Ensure all body parts are clear when stowing Instant Snappy	<b>✓</b>	Relevant training	All

©CATASTROPHIC, @MAJOR, @MODERATE, @MINOR, @INSIGNIFICANT